

Setup and assembly

Your Poovac package should include the following items:

1. Battery
2. Charger
3. Blower/Vacuum Unit
4. Base Unit
5. Suction Stem
6. Pack of 25 Bags
7. 3 x Cross Headed Screws

Assembly will require a screwdriver.



Step 1. Connecting the suction stem with the base unit

Grip one of the tabs on the base unit and raise the hinged part upwards. Align the hole in the base unit with the suction stem, as demonstrated in the image. Push together until there is no gap.



Find the three holes inside the hinged compartment (see image for guidance) and insert the screws accordingly. Use a screwdriver to fasten the two parts together securely.



Close the unit by rotating the suction trunk in an upward motion around the hinge.

Step 2. Attaching the blower unit

The unit will only fit one way. When connected the handle should be at the opposite end to the collection hole. Rest the handle on top of the suction trunk and lock together by using the two clips.

