



How do I use the Poovac?

Operation of the Poovac

To turn on the Poovac, grip the handle at the top of the unit, depress the safety switch (illustrated in the photo below) then squeeze the trigger. When you want to turn the Poovac off, release the trigger.



If the Poovac does not immediately suck up the mess, slightly rotate the unit from side to side as you move the nozzle closer to the mess (as demonstrated in the photo below). Repeat this process until the mess has passed through the suction nozzle.



To see a video clip demonstrating how to use your unit, please go to www.poovac.com/operation.

- Prior to using the Poovac, ensure you have read and understood this instruction manual.
- Ensure you are wearing suitable clothing.
- Ensure the attachments to the Poovac are correctly fitted and adjusted.
- Be aware of other people and animals in the area where you are to be operating the Poovac.
- Wash hands after use.

Maintenance and storage information

Before any cleaning or maintenance, always ensure the battery pack has been removed from the Poovac. When you have finished using the Poovac, always check to make sure the product is clean and free of dirt and debris.

Store the Poovac in a dry place, and out of reach of children.